

Step 1: Decide the IP Addresses

Device	IP Address	Subnet Mask	Default Gateway
Router	192.168.10.1	255.255.255.0	-
PC0	192.168.10.2	255.255.255.0	192.168.10.1
PC1	192.168.10.3	255.255.255.0	192.168.10.1
PC2	192.168.10.4	255.255.255.0	192.168.10.1

Step 2: Configure the Router

1. Click the **Wireless Router**.
2. Go to the **GUI** tab.
3. Find **Setup** (it usually opens automatically).
4. Under **Local IP Address**, enter:

192.168.10.1

5. Set **Subnet Mask** to:

255.255.255.0

6. Click **Save Settings** (if available).
-

Step 3: Configure PC0

1. Click **PC0**.
2. Go to **Desktop**.
3. Click **IP Configuration**.
4. Select **Static**.
5. Enter:

IP Address: 192.168.10.2
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.10.1

Close the window.

Step 4: Configure PC1

Click **PC1** → **Desktop** → **IP Configuration** → **Static**

Enter:

IP Address: 192.168.10.3
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.10.1

Step 5: Configure PC2

Click **PC2** → **Desktop** → **IP Configuration** → **Static**

Enter:

IP Address: 192.168.10.4
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.10.1

Step 6: Test the Network

On **PC0**:

1. Go to **Desktop**.
2. Open **Command Prompt**.
3. Type:

```
ping 192.168.10.3
```