

Q. Write step-by-step instructions to configure the Wi-Fi router for your SOHO network, including setting up a unique SSID, enabling WPA2 security, and changing the default admin password.

### Step 1: Connect the Hardware

1. Connect the broadband internet cable (from your ISP modem/ONT) to the **WAN/Internet** port of the Wi-Fi router.
2. Connect your laptop to the router using a LAN (Ethernet) cable or the default Wi-Fi network.
3. Turn on the router and wait until the power and internet lights become stable.

### Step 2: Log In to the Router

1. Open a web browser (Chrome, Edge, or Firefox).
2. Type the router's default IP address in the address bar. Common addresses are:
  - o **192.168.0.1**
  - o **192.168.1.1**
3. Press **Enter**.
4. Log in using the default username and password.

### Step 3: Change the Default Admin Password

1. Go to **Administration, System Tools, or Management**.
2. Find the **Change Password** or **Admin Password** option.
3. Enter the current password.
4. Create a new strong password using letters, numbers, and symbols.
5. Save the changes.

#### Example:

- Username: `admin`
- New Password: `SOHO@2026Secure`

### Step 4: Set a Unique Wi-Fi Name (SSID)

1. Go to **Wireless Settings**.
2. Locate the **SSID (Wi-Fi Name)** field.
3. Replace the default Wi-Fi name with a unique one.

**Example SSID:** `Om_Home_Office_WiFi`

4. Click **Save** or **Apply**.

### Step 5: Enable WPA2 Security

1. In the **Wireless Security** section, choose:
  - o **Security Mode: WPA2-PSK (AES)**
2. Create a strong Wi-Fi password.

**Example Wi-Fi Password:** Office@12345

3. Save the settings.

## **Step 6: Restart the Router**

1. If prompted, restart the router.
2. Wait for it to reboot completely.

## **Step 7: Connect Your Devices**

Connect the following devices to the new Wi-Fi network:

- Laptop 1
- Laptop 2
- Smart TV

If the printer is connected by Ethernet, plug it into one of the router's LAN ports. If it supports Wi-Fi, connect it to the same Wi-Fi network.

## **Step 8: Test the Network**

1. Open a web browser on each laptop and check if the internet is working.
2. Verify that the Smart TV can access online apps.
3. Print a test page from the printer to confirm it is connected.