

1. Connect Motherboard Main Power Connector

Cable: 24-pin ATX motherboard power cable

Connector on PSU: Commonly marked “MB” or “24-PIN” (for modular PSUs)

Connector on motherboard: 24-pin ATX power connector

Procedure:

Find the big 24-pin connector on the motherboard (typically located at the right edge). Connect the 24-pin ATX cable coming out of the PSU to the 24-pin connector on the Motherboard. Make sure the locking mechanism clicks into place.

2. Connect CPU Power to Motherboard

Cable: 4+4-pin EPS/CPU power cable (which can combine into an 8-pin connector)

Connector on PSU: Commonly marked “CPU” or “EPS”

Connector on motherboard: 8-pin (or 4+4-pin) CPU power connector close to CPU socket

Steps:

Locate the power connector for the CPU near the upper left of the motherboard. Connect the EPS 8-pin cable. Verify that the latch clicks into place.

3. Connect the Graphics Card (GPU)

Cable: PCIe power cable (choose from 6-pin, 8-pin, 6+2-pin, or the newer 12VHPWR/12V-2x6 based on your GPU).

Connector on PSU: Marks as "PCI-E"/“VGA”.

Connector on GPU: Found on the power sockets of the graphics card.

Steps:

Install the GPU into the PCIe x16 slot.

Determine how many power connectors are needed for the GPU.

Connect the corresponding PCIe power cable(s):

Older and midrange GPUs: one or two 6+2-pin connectors.

More modern and high-end GPUs: may need the 12VHPWR, 12V-2x6 connector.

Confirm the connectors are fully seated.

4. Connect SATA SSDs or Hard Drives

Cable: SATA power cable

Connector on PSU: SATA power output

Connector on storage device: 15-pin SATA power connector

Steps:

SSD or HDDs are installed.

Connect a SATA power connector from the PSU to the drive.

Connect a SATA data cable from the drive to a SATA port on the motherboard.

5. Connect More Components (Optional)

Case Fans & RGB Controllers

Cable: SATA power (common) or Molex on older devices

Connector: PSU SATA/Molex connector → fan hub or RGB controller

Optical Drives (if present)

Cable: SATA power cable.

Connector: PSU SATA power → optical drive

Final Check

Ensure the main power cable is properly connected

Ensure the CPU power cable is connected.

Ensure all PCIe power cables for the GPU are connected.

Ensure all SATA drives have both power and data connections.

Make sure all connectors are fully and completely seated before powering on the system.